



# Lenovo IdeaPad 300-17ISK Bottom Back Cover Replacement

Prerequisite Only. Remove the bottom back cover of a Lenovo IdeaPad 300-17ISK.

Written By: Ammar Dodin



## INTRODUCTION

This guide shows how to remove the bottom back cover of your laptop to gain access to the RAM, hard drive, and wireless network card.

The battery for this device is not easily accessible and cannot be easily removed. Before you begin your replacement, be sure to disconnect the laptop from any power source. Additionally, we recommend that you drain the battery completely before you begin this replacement.



### TOOLS:



- [Phillips #1 Screwdriver](#) (1)
-

## Step 1 — Bottom Back Cover



- Unscrew the two 7mm Phillips #1 screws that hold the bottom back plate in its place.

## Step 2



- Place your hands at the bottom of the cover and slide it towards you.
- Lift the cover up to remove it.

To reassemble your device, follow these instructions in reverse order.



